


SNOKONE MACHINES

The SnoKone machine is simple to operate and a great attraction for any event!

The Machine

The machine includes a 110 volt, single phase, 60 cycle, AC current motor with toggle switch, shaving unit, dispensing case, and separate light switch inside the case. A cutterhead is mounted on the end of the motor shaft inside the shaver body (gooseneck). The pusher handle presses the ice against the revolving cutterhead to produce the shaved ice.



NOTE: The machine must be properly grounded to prevent electrical shock.

Tips

1. Start the motor and fill gooseneck an inch from the top with ice cubes or 3" x 4" pieces of ice. (The larger the ice pieces, the better the snow.)
2. Push ice down against the cutterhead with firm pressure for best snow (too much = coarse ice; too little = mushy).
3. DO NOT force the handle.
4. A surface temperature of 150° F. is normal.
5. Put only ice in the gooseneck to prevent damage to the blades.
6. Keep fingers away from shaver body when motor is running to prevent injury.

Cleaning Instructions

1. Unplug the machine.
2. Wipe all surfaces clean to avoid cleaning charges.

Consult your rental center for additional equipment and accessories for your event.



UNDERSTAND YOUR RENTAL CONTRACT KNOW YOUR RESPONSIBILITY FOR THE EQUIPMENT YOU HAVE RENTED

These guidelines and tips are common-sense suggestions designed to promote Snokone machine efficiency and safety. Compiled from literature of leading experts in the field, they are believed to be reliable, and are offered as suggestions and illustrations to deal principally with common practices and conditions encountered in the use of Snokone machines. The guidelines are not intended to be all-inclusive, complete descriptions of safe practices, or to supplant or replace other additional precautionary measures to cover usual or unusual conditions or situations where common sense might otherwise dictate. Accordingly, the American Rental Association and its member firms disclaim all liability for, and make no warranty or guarantee of, the accuracy or applicability of this information in any situation.



american rental association © 1993

FIRST PLACE RENTAL™
4975 ROUTE 71
OSWEGO, IL 60543
(630) 554-3155